Werbestudio Königswinter


PRODUKTBLATT


Flex Wall Large

FLW-L










- **Verstellbar in Höhe und Breite mit Teleskopstangen**
- **System mit geringem Gewicht, einfach zu transportieren und bewegen**
- **Eine großartige Werbwand für jedes Budget**

PRODUKTBLATT

Flex Wall Large

FLW-L



PRODUKTBLATT

Flex Wall Large

FLW-L

BASISINFORMATIONEN

SKU	Größen (mm) (A x B x C)	Format (mm)	Sichtbare Größe (mm) (VXxVY)	Lochabstand (mm) (XxY)
FLW-L	3120 x 2505 x 440	3000 x 2350 mm	3000 x 2350 mm	-

Ausrichtung	Gewicht (kg)
Senkrecht	6,74

ELEKTRISCHE PARAMETER

Beleuchtung	Lichtfarbe (K)	Helligkeit (cd)	Lichtintensität (lm)	Leistung (W)
Nein	-	-	-	-

VERPACKUNGSINFORMATIONEN

Verpackungseinheit 1 (mm)	Verpackungseinheit 2 (mm)	Verpackungseinheit 3 (mm)
1060 x 230 x 110	-	-

Palette Stückzahl	Palettengewicht (kg)	Palettenart
48	427	-

MEHR INFORMATIONEN


Produktzertifizierung	EAN
Nein	8596052144615

MONTAGEANLEITUNGEN

Flex Wall Large

FLW-L

❶ Open the bag and take out all the pieces.




a.Feet (x 2) b.Vertical pole (x 2) c.Lower horizontal piece (x 2)
d.Upper horizontal piece (x 2) e.Screw A (x 4) f.Allen wrench
g.Screw B (x 2)

PS: Plastic arch degree of "d" is clearly larger than that of "c"


❷ Insert vertical pole into the feet and fix by screw B.




❸ Screw on two upper horizontal pieces, and do the same to the lower horizontal pieces.



❹ Slide the upper horizontal pole through top pole pocket on the banner.




❺ Fix upper horizontal pole by screw A.



❻ Slide the bottom horizontal pole through bottom pole pocket on the banner and fix it just like step 5.



❼ Loosen the telescoping clamps on the vertical poles, adjust the banner to be well displayed, then tighten the clamps.



❽ Then you have it.



Disassemble in the reverse order.
Caution: Make sure the graphic is folded neatly and save it in bag after using, to avoid wrinkle.

FLEXWALL